



FIG. 5

8. Reposition the windscreen wiper motor, starter solenoid and horn relay, in the most convenient position, and blank off the original mounting holes.
9. Refit the Bonnet and front Wing Assembly.

Item No.111 ENGINE SUMP GUARD.

JAVELIN - ALL MODELS.

Cases have been reported by overseas agents, that, due to extremely bad road conditions, damage is sustained to the engine sump. To prevent this, a sump Guard has been designed, which can be manufactured and fitted to cars if so desired. The following instructions and sketches will be of assistance in the manufacture and fitting of the sump Guard.

1. Remove the bumper Bracket Frame Assembly from the front end of the chassis frame.
2. Fabricate from $\frac{5}{8}$ " (15.875mm) by 10 Gauge